Portable CD Player

EXP2546

Thank you for choosing Philips.

Need help fast?

Read your Quick Start Guide and/or User Manual first for quick tips that make using your Philips product more enjoyable.
If you have read your instructions and still need assistance, you may access our online help at

www.philips.com/welcome
or call
1-888-PHILIPS (744-5477)
while with your product.
(and Model / Serial number)

Philips vous remercie de votre confiance.

Besoin d'une aide rapide?

Le Guide rapide de début et Manuel de l'utilisateur regorgent d'astuces destinées à simplifier l'utilisation de votre produit Philips. Toutefois, si vous ne parvenez pas à résoudre votre probléme, vous pouvez accéder à notre aide en ligne à l'adresse

www.philips.com/welcome
ou formez le
1-800-661-6162 (Francophone)
1-888-PHILIPS (744-5477) (English speaking)
Veillez à avoir votre produit à portée de main.
(et model / serial nombre)

Gracias por escoger Philips

Necesita ayuda inmediata?

Lea primero la Guía rápida del comienzo o el Manual del usuario, en donde encontrará consejos que le ayudarán a disfrutar plenamente de su producto Philips. Si después de leerlo aún necesita ayuda, consulte nuestro servicio de asistencia en línea en

www.philips.com/welcome
o llame al teléfono
1-888-PHILIPS (744-5477)
y tenga a mano el producto.
(y número de model / serial)

PHILIPS

Return your Product Registration Card today to get the very most from your purchase.

Registering your model with PHILIPS makes you eligible for all of the valuable benefits listed below, so don't miss out. Complete and return your Product Registration Card at once to ensure:

*Proof of Purchase

Returning the enclosed card guarantees that your date of purchase will be on file, so no additional paperwork will be required from you to obtain warranty service.

*Product Safety Notification

By registering your product, you'll receive notification - directly from the manufacturer - in the rare case of a product recall or safety defect.

*Additional Benefits of Product Ownership

Registering your product guarantees that you'll receive all of the privileges to which you're entitled, including special money-saving offers.

PHILIPS

Congratulations on your purchase, and welcome to the "family!"

Dear PHILIPS product owner:

Thank you for your confidence in PHILIPS. You've selected one of the best-built, best-backed products available today. We'll do everything in our power to keep you happy with your purchase for many years to come.

As a member of the PHILIPS "family," you're entitled to protection by one of the most comprehensive warranties and outstanding service networks in the industry. What's more, your purchase guarantees you'll receive all the information and special offers for which you qualify, plus easy access to accessories from our convenient home shopping network.

Most importantly, you can count on our uncompromising commitment to your total satisfaction.

All of this is our way of saying welcome - and thanks for investing in a PHILIPS product.

P.S. To get the most from your PHILIPS purchase, be sure to complete and return your Product Registration Card at once.

Know these **safety** *symbols*

CAUTION
RISK OF ELECTRIC SHOCK
DO NOT OPEN
CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

This "bolt of lightning" indicates uninsulated material within your unit may cause an electrical shock. For the safety of everyone in your household, please do not remove product covering.

The "exclamation point" calls attention to features for which you should read the enclosed literature closely to prevent operating and maintenance problems.

WARNING: To reduce the risk of fire or electric shock, this apparatus should not be exposed to rain or moisture, and objects filled with liquids, such as vases, should not be placed on this apparatus.

CAUTION: To prevent electric shock, match wide blade of plug to wide slot, fully insert.

ATTENTION: Pour éviter les choc électriques, introduire la lame la plus large de la fiche dans la borne correspondante de la prise et pousser jusqu'au fond.

For Customer Use

Enter below the Serial No. which is located on the rear of the cabinet. Retain this information for future reference.

Model No. _____

Serial No. _____

IMPORTANT SAFETY INSTRUCTIONS

1. **Read these instructions.**
2. **Keep these instructions.**
3. **Heed all warnings.**
4. **Follow all instructions.**
5. **Do not use this apparatus near water.**
6. **Clean only with a dry cloth.**
7. **Do not block any of the ventilation openings. Install in accordance with the manufacturers instructions.**
8. **Do not install near any heat sources** such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
9. **Only use attachments/accessories** specified by the manufacturer.
10. **Use only with a cart**, stand, tripod, bracket, or table specified by the manufacturer or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.

11. **Refer all servicing** to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as if the power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, or when the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

12. **Battery usage CAUTION** – To prevent battery leakage which may result in bodily injury, property damage, or damage to the unit:

- Install **ALL** batteries correctly, **+** and **-** as marked on the unit.
- Do not mix batteries (**OLD** and **NEW** or **CARBON** and **ALKALINE** etc.).
- Remove batteries when the unit is not used for a long time.

13 **Apparatus shall not be exposed to dripping or splashing**

14 **Do not place any sources of danger on the apparatus**. (e.g. liquid filled objects, lighted candles).

15 This product may contain lead and mercury. Disposal of these material may be regulated due to environment considerations. **For disposal or recycling information, please contact your local authorities or the Electronic Industries Alliance : www.eiae.org.**

EL 6475-E005: 04/01

COPYRIGHT INFORMATION

The making of unauthorized copies of copy-protected material, including computer programmes, files, broadcasts and sound recordings, may be an infringement of copyrights and constitute a criminal offence. This equipment should not be used for such purposes.

DISPOSAL OF YOUR OLD PRODUCT

Your product is designed and manufactured with high quality materials and components, which can be recycled and reused.



When this crossed-out wheeled bin symbol is attached to a product it means the product is covered by the European Directive 2002/96/EC.

Please inform yourself about the local separate collection system for electrical and electronic products.

Please act according to your local rules and do not dispose of your old products with your normal household waste. The correct disposal of your old product will help prevent potential negative consequences for the environment and human health.

IMPORTANT!

Hearing safety: listen at a moderate volume, using headphones at high volume can impair your hearing.
Important: Philips guarantees compliance with the maximum sound power of its audio players as determined by relevant regulatory bodies only with the original model of provided headphones. In case this one needs replacement, we recommend that you contact your retailer to order a model identical to that of the original, provided by Philips.

Traffic safety: Do not use headphones while driving a vehicle. It may create a hazard and it is illegal in many countries. Even if your headphones are an open-air type designed to let you hear outside sounds, do not turn up the volume so high that you cannot hear what is going on around you.

CAUTION

- *Use of controls or adjustments or performance of procedures other than herein may result in hazardous radiation exposure.*
- *Apparatus should not exposed to dripping of splashing,*
- *do not place any sources of danger on apparatus (e.g. liauid filled objects, lighted candle.*

Canada

English

This digital apparatus does not exceed the Class B limits for radio noise emissions from digital apparatus as set out in the Radio Interference Regulations of the Canadian Department of Communications.

Français

Cet appareil numérique n'émet pas de bruits radioélectriques dépassant les limites applicables aux appareils numériques de Classe B prescrites dans le Règlement sur le Brouillage Radioélectrique édicté par le Ministère des Communications du Canada.

1


1
2
3
4
5
6
7
8
9
10
11
12
OPEN
MODE
DSB/ESP
VOL-
VOL+
MP3Δ
▽MP3
▷II
□
⏮
⏭

2


1
2
3
4
5
6
7
8
9
10
ESP
DBB
MP3
1-
SCAN
888
88:88

1 OPEN



2 AA





3 CD





4



5 PLAY ▶II



6 VOL



7 STOP ■



!!!





CONTROLS (see figure 1)

① OPEN ▶ .....opens the CD lid

② – VOL + ...adjust the volume

③ DBB/ESP.....press briefly to switch the bass enhancement(DBB) on/off. Press and hold to switch the Electronic Shock Protection (ESP) on/off.

④ MODE .....selects the different playing possibilities:

To return to normal playback

1 : The current track is played repeatedly

: The entire CD is played repeatedly.

SCAN : The first 10 seconds of each of the remaining tracks are played in sequence

: All tracks of the CD are played in random order until all of them have been played once

⑤ 🎧/LINE OUT.....3.5 mm headphone socket (headphone AY3806)

⑥ .....LCD display

⑦ MP3 ▲ ▼.....MP3 only: skips forward/backward albums

⑧ ▶II ⏻ .....switches the player on, starts or pauses CD play

⑨ ■.....stops CD play, switches the player off

⑩ ⏮.....skips and searches CD tracks backwards

⑪ ⏭.....skips and searches CD tracks forwards

⑫ 4.5V/450mA DC..socket for external power supply "AY3162 (not included)"

CONTROLS / POWER SUPPLY

LCD display (see figure 2)

① Track number
② Electronic Skip Protection (45 sec)
③ Base enhancement
④ Battery empty
⑤ MP3 indicator
⑥ Repeat 1 track / Repeat all track
⑦ Scan tracks
⑧ Shuffle all track
⑨ MP3 album number (Display album # when pressing **MP3 ▲/▼**)
⑩ Playing time

Batteries (not included)

You can use the following batteries with this CD-player:

- normal batteries type **LR6, UM3** or **AA** (preferably Philips), or
- alkaline batteries type **LR6, UM3** or **AA** (preferably Philips).

CAUTION

– Batteries contain chemical substances, so they should be disposed of properly.
– Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type.
– Incorrect use of batteries can cause electrolyte leakage and will corrode the compartment or cause the batteries to burst.
– Old and new or different types of batteries should not be combined.
– Remove the batteries if the set is not to be used for a long time.

CD PLAY / GENERAL INFORMATION

Playback information

- When playing a CD-Rewritable (CD-RW), please note that it takes 3–15 seconds after pressing ▶II for sound reproduction to start.
- Playback will stop if you open the CD lid.
- While the CD is read, rEAd flashes in the display.

CD player and CD handling



- Do not touch the lens Ⓐ of the CD player.
- Do not expose the unit, batteries or CDs to humidity, rain, sand or excessive heat (caused by heating equipment or direct sunlight).
- You can clean the CD player with a soft, slightly dampened, lint-free cloth. Do not use any cleaning agents as they may have a corrosive effect.
- To clean the CD, wipe it in a straight line from the center toward the edge using a soft, lint-free cloth. A cleaning agent may damage the disc! Never write on a CD or attach a sticker to it.
- The lens may cloud over when the unit is moved suddenly from cold to warm surroundings. Playing a CD is not possible then. Leave the CD player in a warm environment until the moisture has evaporated.
- Active mobile phones in the vicinity of the CD player may cause malfunctions.
- Avoid dropping the unit as this may cause damage.

ABOUT MP3

The music compression technology MP3 (MPEG1 Audio Layer 3) significantly reduce the digital data of an audio CD while maintaining CD quality sound.

- **Getting MP3 files**: you can either download legal music files from the internet to your computer hard disc, or create such files by converting audio CD files in your computer through appropriate encoder software. (128kbps bit rate or higher is recommended for MP3 files.)
- **Creating a MP3 CD**: burn the music files from your computer hard disc on a CDR or CDRW using your CD burner.

Helpful Hints:

– *Make sure that the file names of the MP3 files end with* ***.mp3*** *.*

– *Total number of music files and albums: around 999 (with a typical file name length of 20 characters)*

– *The length of file names affects the number of tracks for playback. With shorter file names, more files can be burned on a disc.*

Environmental information

- All redundant packing material has been omitted. We have done our utmost to make the packaging easily separable into two materials: cardboard (box) and polyethylene (bags, protective foam sheet).
- Your set consists of materials which can be recycled if disassembled by a specialized company. Please observe the local regulations regarding the disposal of packing materials, exhausted batteries and old equipment.

Troubleshooting

WARNING: *Under no circumstances should you try to repair the set yourself as this will invalidate the warranty. If a fault occurs, first check the points listed, before taking the unit for repair. If you are unable to solve a problem by following these hints, consult your dealer or service center.*

The CD player has no power, or playback does not start

- Check that your batteries are not dead or empty, that they are inserted correctly, that the contact pins are clean.
- Your adapter connection may be loose. Connect it securely.
- For in-car use, check that the car ignition is on. Also check player's batteries.

The indication Err is displayed

- Check that the CD is clean and correctly inserted (label-side upward).
- If your lens has steamed up, wait a few minutes for this to clear.

Music files do not play

- Check that the file names of MP3 files end with .mp3.

Some directories missing on MP3 CDs

- Check that the total number of files and albums on your MP3 CDs does not exceed 999.
- Only albums with MP3 files are shown.

The CD skips tracks

- The CD is damaged or dirty. Replace or clean the CD.
- SHUFFLE is active. Switch off whichever is on.

Music skips or popping sounds when you play a MP3 track

- Play the music file in your computer. If the problem remains, encode the audio track again and make a new CD.

No sound or bad sound quality.

- CD-RW (CD-R) was not recorded properly. Use FINALIZE on your CD-recorder.
- PAUSE might be active. Press ▶II.

Troubleshooting

- Loose, wrong or dirty connections. Check and clean connections.
- Volume might not be appropriately adjusted. Adjust the volume.
- Strong magnetic fields. Check player's position and connections. Also keep away from active mobile phones.
- *For in-car use,* check that the cassette adapter is inserted correctly, that the car cassette player's playback direction is correct (press autoreverse to change), and that the cigarette lighter jack is clean. Allow time for temperature change.

The set complies with the FCC-Rules, Part 15 and with 21 CFR 1040.10. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifi cations made to this equipment not expressly approved by Philips could void the user's authority to operate this equipment.

PHILIPS CONSUMER ELECTRONICS COMPANY

Philips Consumer Lifestyle

A Division of Philips Electronics North America Corporation

P.O.BOX 671539, Marietta, GA. 30006-0026

Meet Philips at the Internet

http://www.philips.com/welcome

CLASS 1
LASER PRODUCT

Be responsible
Respect copyrights

Specifications are subject to change without notice.

Trademarks are the property of Koninklijke Philips Electronics N.V.
or their respective owners

2009 © Koninklijke Philips Electronics N.V. All rights reserved.

Printed in China

EXP2546_17_UM_V3.0